

PRO-920/1120HD IR CODES

CATEGORY	FUNCTION	COMMAND 1	COMMAND 2
POWER	STANDBY/ON	AA 1C	
	ON	AA 1A	
	OFF	AA 1B	
	SLEEP	AA 48	
VOLUME	VOLUME UP	AA 0A	
	VOLUME DOWN	AA 0B	
	MUTE	AA 49	
INPUT	INPUT TOGGLE	AA 13	
	INPUT 1	AA 0F	
	INPUT 2	AA 0E	
	INPUT 3	AA 56	
	INPUT 4	AA DE	
	PC	AA D3	AF 33
	ANTENNA	AA 45	
TUNER	i.LINK	AA D5	AF 60
	1	AA 01	
	2	AA 02	
	3	AA 03	
	4	AA 04	
	5	AA 05	
	6	AA 06	
	7	AA 07	
	8	AA 08	
	9	AA 09	
	0	AA 00	
	PERIOD (.)	AA C3	
	CHANNEL UP	AA 10	
	CHANNEL DOWN	AA 11	
	CHANNEL ENTER	AA 1F	
	CHANNEL RETURN	AA 5C	
	DTV INFO	AA D3	AF DB
	DTV GUIDE	AA D4	AF 61
	FAVORITE A	AA D4	AF 74
	FAVORITE B	AA D4	AF 71
	FAVORITE C	AA D4	AF 72
FAVORITE D	AA D4	AF 73	
MTS	AA 1E		
SETUP	MENU	AA 8B	
	RETURN	AA D3	AF 74
	UP ARROW	AA 96	
	DOWN ARROW	AA 97	
	RIGHT ARROW	AA 94	
	LEFT ARROW	AA 95	
	SET/ENTER	AA 8A	
	SCREEN SIZE	AA D3	AF 3C
	A/V SELECT	AA 59	
DISPLAY	AA 4A		
PIP	SPLIT	AA D5	AF 20
	SWAP	AA D5	AF 25
	SHIFT PIP	AA D5	AF 27
	FREEZE	AA 18	